



OUTDOOR

①



Tap once to turn on, then tap the switch again to turn off



②

